PEOPLESAFE

RIPCORD

Ripcord Alarm

If the lanyard is detached from the device a 10-second pre-warning alarm beeps before an alarm is raised to the ARC.

To cancel this alarm, re-insert the lanyard loop piece back into the device before the audio beeps stop.

LED SCREEN

View the remaining battery, GPS signal, network, mobile strength, time and unique IMEI number with a **single press** of the **power button**. The LED screen will display for a few seconds before entering sleep mode to conserve battery.

CALL BUTTON

Voice Memo

Press and hold for **3 seconds**. Record vital information for the Peoplesafe ARC in the event of an alarm.

Test Line

Double press and leave a message. Listen to the message playback to check the sound quality.

SOS BUTTON

SOS Alarm

Press and hold for **4 seconds**. The device will vibrate and connect to the ARC. If you activate the alarm by mistake, inform the controller by stating "False alarm".

Device display:
95% 4G
10:17
GPRS CONNECTED
IMEI:863921039915726

POWER BUTTON

Power On/Off

Press and hold for **4 seconds** to turn on/off. The LED screen will state Power Off before the device turns off.

Manual Position

Press and hold for **2 seconds**. The LED screen will state Manual Position when your GPS location has been sent to Peoplesafe.

VOICE MEMO

Before meeting a client, starting an appointment or commencing a task, leave a message with vital information for the ARC. For example, the name of the person you are visiting, the flat number or what floor you are on. If sharing the device state your name. The alarm controller can listen to voice memos for alarms raised within 24 hours of recording the memo.

To activate: Press and hold the call button for 3 seconds.

TEST LINE

Have confidence that the device will work when you need it most. Perform a test call to ensure the device is registered and check the sound quality. We recommend completing this test every three months.

To activate: Double press the call button.

USEFUL NUMBERS

Save the Peoplesafe ARC phone numbers to your contact list on your smartphone.

+4420 3 750 0998
+4420 8 786 1010

For more information download the user guide from our Help Centre.

PEOPLESAFE

MO ELSOPKI

SECURITY CARD

TEL: 0800 990 3563   WWW.PEOPLESAFE.CO.UK

ID140-TL-VM-HTG01

KEEP IT SWITCHED ON | KEEP IT CHARGED | KEEP IT WITH YOU | KEEP SAFE