

RIPCORD

Ripcord Alarm

If the lanyard is detached from the device a 10-second pre-warning alarm beeps before an alarm is raised to the ARC.

To cancel this alarm, re-insert the lanyard loop piece back into the device before the audio beeps stop.

LED SCREEN

View the remaining battery, GPS signal, network, mobile strength, time and unique IMEI number with a **single press** of the **power button**. The LED screen will display for a few seconds before entering sleep mode to conserve battery.

CALL BUTTON

Timed Activity

Press and hold for 3 seconds to set a timer at the start of an appointment or activity. The system will check on your welfare when the timer expires. If no response after the timer has expired an alarm will be raised

Test Line

Double press and leave a message. Listen to the message playback to check the sound quality.

SOS BUTTON

SOS Alarm

Press and hold for 4 seconds. The device will vibrate and connect to the ARC. If you activate the alarm by mistake, inform the controller by stating "False alarm".



POWER BUTTON

Power On/Off

Press and hold for 4 seconds to turn on/off. The LED screen will state Power Off before the device turns off.

Manual Position

Press and hold for 2 seconds. The LED screen will state Manual Position when your GPS location has been sent to Peoplesafe.



TIMED ACTIVITY

Before meeting a client, starting an appointment or commencing a task, set a timed activity by following the voice prompts. The system will check on your welfare if this timer expires, and if there is no response an alarm will be raised to the ARC. By default, a 60- minute timer will begin. This can be amended in the portal.

To activate: Press and hold the call button for 3 seconds.



TEST LINE

Have confidence that the device will work when you need it most. Perform a test call to ensure the device is registered and check the sound quality. We recommend completing this test every three months.

To activate: Double press the call button.

USEFUL NUMBERS

Save the Peoplesafe ARC phone numbers to your contact list on your smartphone.

+44203 750 0998

+44208 786 1010

For more information download the user guide from our Help Centre.



ID140-TL-TA-HTG01